



Industrial Conveyor Specialists

**Installation, Maintenance & Parts Manual
For**

**MODEL 208
Floor to Floor
Slider Bed Conveyor**

For Additional copies of this manual, please visit our website at
www.titanconveyors.com

Go to Info Center, Select the Maintenance Manual Tab
and select the manual for your model conveyor
or click on the link below.


<https://www.titanconveyors.com/info-center#823236-maintenance-manuals>




**Titan Conveyors
735 Industrial Loop Road
New London, WI 54961
920-982-6600
800-558-3616
FAX 920-982-7750**

**E-mail: sales@titanconveyors.com
Website: www.titanconveyors.com**

Serial No.




31. UPPER SUPPORT
32. SMILE BRACKET
33. SUPPORT SPLICE ANGLE
34. ●BELT
35. ●RETURN ROLLER
36. RETURN ROLLER BRACKET
37. SIDEMOUNT DRIVE GUARD
38. SIDEMOUNT DRIVE MOTOR BASE
39. GUARD TOP MT. DRIVE
40. GUARD BACK TOP MT. DRIVE
41. TOP MT. DR. ADAPTOR PLATE L/H
42. TOP MT. ADAPTOR PLATE R/H
43. LOWER GUARD TOP MT. DRIVE
44. SIDERAILS
45. ●TAIL PULLEY SHAFT
46. ●DRIVE PULLEY SHAFT
47. ●ROLLER CHAIN



1. LARGE GUARD C.D. & T.U.
2. ● **SNUB PULLEY**
3. ● **SNUB PULLEY SHAFT**
4. THREADED ROD
5. HEX JAM NUT
6. C.D. & T.U. PLATE L/H
7. ● 1 3/16" **BEARING,3 BOLT FLANGE**
8. ● **TAKE-UP SHAFT**
9. HEX NUT
10. ● **TAKE-UP BEARING**
11. ● 1 7/16" **BEARING,3 BOLT FLANGE**
12. GUARD BACK
13. GUARD FRONT
14. L-CLIP
15. SMALL GUARD C.D.& T.U.
16. ● **DRIVE PULLEY**
17. ● **DRIVE SHAFT**
18. MOTOR BASE
19. ● **REDUCER**
20. ● **MOTOR**
21. C.D. & T.U. PLATE R/H
22. ● **TAKE-UP PULLEY**
23. ● **DRIVE SPROCKET**
24. ● **DRIVEN SPROCKET**
25. TAKE-UP GUARD
26. ● **ROLLER CHAIN**

MODEL 208 POWER FEEDER CONVEYOR



- | | | |
|--|---|---------------------------------------|
| 1. • POWER FEEDER INFEED PULLEY | 10. GUARD BACK BRACKET | 17. TAKE-UP BAR INCLINE L/H |
| 2. INFEED TAKE-UP PLATE POWER FEEDER L/H | 11. • POWER FEEDER DRIVE SPROCKET | 18. INFEED FRAME |
| 3. • 3 BOLT FLANGE BEARING | 12. GUARD BACK | 19. • BELT |
| 4. TAKE-UP BOLT | 13. GUARD FRONT | 20. TAKE-UP BAR INCLINE R/H |
| 5. POWER FEEDER FRAME | 14. • POWER FEEDER DRIVE PULLEY | 21. SUPPORT SPLICE ANGLE |
| 6. • POWER FEEDER BELT | 14A. • POWER FEEDER DRIVE PULLEY SHAFT | 22. SMILE BRACKET |
| 7. POWER FEEDER HEADPLATE L/H | 15. • INCLINE INFEED PULLEY | 23. UPPER SUPPORT |
| 8. INFEED TAKE-UP PLATE POWER FEEDER R/H | 15A. • INCLINE INFEED PULLEY SHAFT | 24. LOWER SUPPORT |
| 9. POWER FEEDER HEADPLATE R/H | 16. RETAINER CHANNEL | 25. • DRIVE CHAIN POWER FEEDER |
| | | 26. • INFEED PULLEY SHAFT |
- RECOMMENDED SPARE PARTS TO BE STOCKED AT YOUR LOCATION**